HYUNDA POWER EQUIPMENT

Diesel Generator Standby Power 44KVA 3 Phase 1500 rpm DHY45KE DHY45KSE



All Days | Safty | Reliable | Stability



TECHNICAL SPECIFICATION

DHY45KE OPEN TYPE / DHY45KSE CANOPY TYPE

Benefits and Feature

- > Use best quality vehicle engine, low fuel consumption, running reliable
- > Use high quality and performance brushless alternator, with AVR
- > High quality controller of COMAP/ DEEPSEA
- > Block design electrical control system, easy operate and maintenance

Technical Specification

Prime Power	KVA/ KV	40/32
Standby Power	KVA/ KW	44 / 35.2
Power Factor		0.8
Frequency	Hz	50
Rate Voltage	V	400/230
Rate Current	А	63.5
Controller	(Comap/deepsea
Control Voltage	DC / V	24
Battery Capacity	Ah	60x2
Coolant Capacity	L	11.26
Fuel Tank Capacity(Base frame)	L	75
Fuel Consumption	L/hour	11.77
Running Time	Hour	8.5

> Standard 8 hours generator running base frame fuel tank (100% load)

- > With baseframe forklift hole and generator canopy lifting hole
- > Industrial waterproof canopy, ensure generator all days running

50Hz

Standby 44KVA

- > Industrial silencer (7 meters the noise is lower than 68 dB)
- > Easy operation , IP23 protection industrial sockets and plugs
- > Four pole circuit breaker with RCD earth protection
- > Standard ATS function connector

Voltage		
Steady state regulation	%	≤ ± 0.5
Dynamic voltage renewal	%	≤+20~-15
Stable time	Sec	2.0
Waveform distortion		≤3
Volatility		≤0.5
Frequency		
Steady state regulation	%	≤±1
Dynamic frequency renewal	%	≤+10~-7
Stable time	Sec	≤3
Volatility		≤0.5
Environment require		
Temperature	С	≤40
Humidity	%	≤60
Altitude	m	≤1000
Standard		

ISO3046, ISO8528, ISO9001-2008

Dimension | Weight | Sound



DHY45KE **OPEN TYPE** Length mm

Width (W)	mm	780
Height (H)	mm	1080
Weight net	Kg	820
loading capacity (units/container	r)	
Sound @7 meter	dB	92



DHY45KSE CANOPY TYPE

Length	mm	2100
Width (W)	mm	900
Height (H)	mm	1400
Weight net	Kg	940
loading capacity (units/container)		
Sound @7 meter	dB	68

Note

1. Generator continuous running at variable load for unlimited periods with 10% overload available for 1 hour in any 12 hours period

1950

2. Every generator strictly test on 0%, 25%, 75%, 100%, 110% load dynamic responsiveness ability, and all protections



Powerful engine and reliable running quality Durable running performance and was proofed by vehicle's application

Compact structure

Compact structure and metal materials saving for low cost

Low maintenance and repair cost Air,fuel and oil tubes are silicone and stainless steel materials, which reduce leakage problems substantially

Excellent start performance Fuel injector and pump were tested fully in Various environments, which provide excellent start and running performance

DIESEL ENGINE

	Model		HY4105D
	Prime power	Kw	38
	Structure		4 cylinder,inline
	Fuel type		Diesel
	Fuel consumption	L/Hour	11.77
	Lubricant consumption	L/Hour	0.054
	Governor		Electronic
	Coolling		Water
	Lubricant capacity	Lan	12.5
	Air intake flow	m ³ /min	3.1
	Exhaust gas flow	m ³ /min	9.3
-	Exhaust gas temperature	°C	550
	Exhaust gas back pressure	KPa	6.7
2	Compression ratio	1	17
	Aspiration		Natural
	Bore	mm	102
	Stroke		118
	Displacement	L	3.86
	SAE		3/11.5
	Dimension	mm	$870 \times 770 \times 680$
	Net weight	Kg	350

ALTERNATOR

	184J
kVA	40
	1 bearing
	Self-excitation
STATISTICS.	Н
	IP23
5	<50
and the	<2%
m³/s	0.216
12 ×	SX460



Best structure Excellent design ensures compact structure and perfect appearance

Excellent performance Excitation enhanced system improves start and short circuit's protection performance

Economy Less parts involved and the most market's demand lead to cheap price and fine quality

Easy maintenance and repair Core parts won't be involved in repair job, AVR can be replaced easily, examining diode doesn't disassemble rotor

CONTROL PANEL

3

Controller



Comap AMF20

Support engine and alterantor monitoring, measurement and protection. This is long-running and back-up unit to integrate the best way to control, support Modbus standard, modem, RS485, USB and internet.

Deepsea DSE6120



DSE6110/20 MKIII AUTO START & AUTO MAINS (UTILITY) FAILURE CONTROL MODULES

Measurement, displayment Genset prime power Kw Power factor Engine speed Phase to neutral voltage Phase to phase voltage Genset frequency Genset current Mains Phase to neutral voltage Mains Phase to neutral voltage Mains Phase to neutral voltage Mains Phase to phase voltage Mains frequency Engine oil pressure Engine water temperature Fuel level Battery voltage Genset output KWh History file Alarm, shutdown function Low oil pressure warning, shutdown High water temperature warning, shutdown High water temperature warning, shutdown Low oil pressure warning, shutdown Battery low and high voltage warning Battery low and high voltage warning Battery chargering failure Genset low and high voltage warning, shut down Alternator 3 phase voltage unbalance shut down Alternator 1 ow and high frequency warning, shut down Alternator 3 phase current unbalance shutdown
Power factorImage: SpeedEngine speedImage: SpeedPhase to neutral voltageImage: SpeedPhase to phase voltageImage: SpeedGenset frequencyImage: SpeedGenset currentImage: SpeedMains Phase to neutral voltageImage: SpeedMains Phase to phase voltageImage: SpeedMains Phase to phase voltageImage: SpeedMains Phase to phase voltageImage: SpeedMains frequencyImage: SpeedEngine oil pressureImage: SpeedEngine water temperatureImage: SpeedFuel levelImage: SpeedBattery voltageImage: SpeedGenset power KVAImage: SpeedGenset output KWhImage: SpeedHistory fileImage: Speed ShutdownLow oil pressure warning, shutdownImage: Speed ShutdownEngine over and under speed shutdownImage: Speed ShutdownEngine over and under speed shutdownImage: Speed ShutdownEngine over and high voltage warningImage: Speed ShutdownEngine over and high voltage warningImage: Speed ShutdownEngine over and high voltage warning, shut downImage: Speed ShutdownAlternator 3 phase voltage unbalance shut downImage: Speed ShutdownAlternator I ow and high frequency warning, shut downImage: Speed ShutdownAlternator 3 phase current unbalance shut downImage: Speed ShutdownAlternator 3 phase current unbalance shutdownImage: Speed ShutdownAlternator 3 phase current unbalance shutdownImage: Speed Shutdown </th
Engine speedPhase to neutral voltagePhase to phase voltageGenset frequencyGenset currentMains Phase to neutral voltageMains Phase to neutral voltageMains Phase to phase voltageMains Phase to phase voltageMains frequencyEngine oil pressureEngine water temperatureFuel levelBattery voltageGenset power KVAGenset output KWhHistory fileAlarm, shutdown functionLow oil pressure warning, shutdownHigh water temperature warning, shutdownEngine over and under speed shutdownBattery low and high voltage warningBattery low and high voltage warning, shut downAlternator 3 phase voltage unbalance shut downAlternator 3 phase current unbalance shutdownAlternator 3 phase current unbalance shutdown
Phase to phase voltagePhase to phase voltageGenset frequencyGenset currentMains Phase to neutral voltageMains Phase to phase voltageMains Phase to phase voltageMains frequencyEngine oil pressureEngine water temperatureFuel levelBattery voltageGenset power KVAGenset output KWhHistory fileAlarm, shutdown functionLow oil pressure warning,shutdownEngine over and under speed shutdownHigh water temperature warningBattery low and high voltage warningBattery low and high voltage warning, shut downAlternator 3 phase voltage unbalance shut downAlternator 3 phase current unbalance shutdownAlternator 3 phase current unbalance shutdown
Phase to phase voltageGenset frequencyGenset currentMains Phase to neutral voltageMains Phase to phase voltageMains Phase to phase voltageMains frequencyEngine oil pressureEngine water temperatureFuel levelBattery voltageGenset nunning timeGenset output KWhHistory fileAlarm, shutdown functionLow oil pressure warning, shutdownEngine over and under speed shutdownHigh water temperature warningEngine over and under speed shutdownAtterny low and high voltage warningBattery low and high voltage warning, shut downAlternator 3 phase voltage unbalance shut downAlternator 3 phase current unbalance shutdownAlternator 3 phase current unbalance shutdown
Genset current●Mains Phase to neutral voltage○Mains Phase to phase voltage○Mains frequency○Engine oil pressure●Engine water temperature●Fuel level●Battery voltage●Genset power KVA●Genset running time●Genset output KWh●History file●Alarm, shutdown function●Low oil pressure warning,shutdown●High water temperature warning,shutdown●Engine over and under speed shutdown●Battery low and high voltage warning●Battery chargering failure●Genset low and high voltage warning, shut down●Alternator 3 phase voltage unbalance shut down●Alternator 3 phase current unbalance shutdown●Alternator 3 pha
Genset current●Mains Phase to neutral voltage○Mains Phase to phase voltage○Mains frequency○Engine oil pressure●Engine water temperature●Fuel level●Battery voltage●Genset power KVA●Genset running time●Genset output KWh●History file●Alarm, shutdown function●Low oil pressure warning,shutdown●High water temperature warning,shutdown●Engine over and under speed shutdown●Battery low and high voltage warning●Battery chargering failure●Genset low and high voltage warning, shut down●Alternator 3 phase voltage unbalance shut down●Alternator 3 phase current unbalance shutdown●Alternator 3 pha
Mains Phase to neutral voltageImage: Construct of Construc
Mains Phase to phase voltageMains frequencyEngine oil pressureEngine water temperatureFuel levelBattery voltageGenset power KVAGenset running timeGenset output KWhHistory fileAlarm, shutdown functionLow oil pressure warning, shutdownHigh water temperature warning, shutdownEngine over and under speed shutdownLow fuel level warning, shutdownBattery low and high voltage warningBattery chargering failureGenset low and high frequency warning, shut downAlternator 3 phase voltage unbalance shut downAlternator 3 phase current unbalance shutdownAlternator 3
Mains frequencyImage: Construct of the second s
Engine oil pressure●Engine water temperature●Fuel level●Battery voltage●Genset power KVA●Genset running time●Genset output KWh●History file●Alarm, shutdown function●Low oil pressure warning, shutdown●High water temperature warning, shutdown●Low fuel level warning, shutdown●Battery low and high voltage warning●Battery chargering failure●Genset low and high frequency warning, shut down●Alternator 3 phase voltage unbalance shut down●Alternator 3 phase current unbalance shutdown●Alternator 3 phase current unbalance shutdown●
Genset output KWh●History file●Alarm, shutdown function●Low oil pressure warning,shutdown●High water temperature warning,shutdown●Engine over and under speed shutdown●Low fuel level warning, shutdown●Battery low and high voltage warning●Battery chargering failure●Genset low and high voltage unbalance shut down●Alternator 3 phase voltage unbalance shut down●Alternator 1ow and high frequency warning,shut down●Alternator 3 phase current unbalance shutdown●Alternator 3 phase current unbalance shutdown●
Genset output KWh●History file●Alarm, shutdown function●Low oil pressure warning,shutdown●High water temperature warning,shutdown●Engine over and under speed shutdown●Low fuel level warning, shutdown●Battery low and high voltage warning●Battery chargering failure●Genset low and high voltage unbalance shut down●Alternator 3 phase voltage unbalance shut down●Alternator 1ow and high frequency warning,shut down●Alternator 3 phase current unbalance shutdown●Alternator 3 phase current unbalance shutdown●
Genset output KWh●History file●Alarm, shutdown function●Low oil pressure warning,shutdown●High water temperature warning,shutdown●Engine over and under speed shutdown●Low fuel level warning, shutdown●Battery low and high voltage warning●Battery chargering failure●Genset low and high voltage unbalance shut down●Alternator 3 phase voltage unbalance shut down●Alternator 1ow and high frequency warning,shut down●Alternator 3 phase current unbalance shutdown●Alternator 3 phase current unbalance shutdown●
Genset output KWh●History file●Alarm, shutdown function●Low oil pressure warning,shutdown●High water temperature warning,shutdown●Engine over and under speed shutdown●Low fuel level warning, shutdown●Battery low and high voltage warning●Battery chargering failure●Genset low and high voltage unbalance shut down●Alternator 3 phase voltage unbalance shut down●Alternator 1ow and high frequency warning,shut down●Alternator 3 phase current unbalance shutdown●Alternator 3 phase current unbalance shutdown●
Genset output KWh●History file●Alarm, shutdown function●Low oil pressure warning,shutdown●High water temperature warning,shutdown●Engine over and under speed shutdown●Low fuel level warning, shutdown●Battery low and high voltage warning●Battery chargering failure●Genset low and high voltage unbalance shut down●Alternator 3 phase voltage unbalance shut down●Alternator 1ow and high frequency warning,shut down●Alternator 3 phase current unbalance shutdown●Alternator 3 phase current unbalance shutdown●
Genset output KWh●History file●Alarm, shutdown function●Low oil pressure warning,shutdown●High water temperature warning,shutdown●Engine over and under speed shutdown●Low fuel level warning, shutdown●Battery low and high voltage warning●Battery chargering failure●Genset low and high voltage unbalance shut down●Alternator 3 phase voltage unbalance shut down●Alternator 1ow and high frequency warning,shut down●Alternator 3 phase current unbalance shutdown●Alternator 3 phase current unbalance shutdown●
History fileImage: State of the
Alarm, shutdown functionLow oil pressure warning,shutdown●High water temperature warning,shutdown●Engine over and under speed shutdown●Low fuel level warning, shutdown●Battery low and high voltage warning●Battery chargering failure●Genset low and high voltage unbalance shut down●Alternator 3 phase voltage unbalance shut down●Genset over load shutdown●Alternator 3 phase current unbalance shutdown●
Low oil pressure warning, shutdown•High water temperature warning, shutdown•Engine over and under speed shutdown•Low fuel level warning, shutdown•Battery low and high voltage warning•Battery chargering failure•Genset low and high voltage warning, shut down•Alternator 3 phase voltage unbalance shut down•Genset over load shutdown•Alternator 3 phase current unbalance shutdown•
High water temperature warning,shutdownEngine over and under speed shutdownLow fuel level warning, shutdownBattery low and high voltage warningBattery chargering failureGenset low and high voltage warning, shut downAlternator 3 phase voltage unbalance shut downGenset over load shutdownGenset over load shutdownAlternator 3 phase current unbalance shutdown
Low fuel level warning, shutdownBattery low and high voltage warningBattery chargering failureGenset low and high voltage warning, shut downAlternator 3 phase voltage unbalance shut downAlternator low and high frequency warning, shut downGenset over load shutdownAlternator 3 phase current unbalance shutdown
Low fuel level warning, shutdownBattery low and high voltage warningBattery chargering failureGenset low and high voltage warning, shut downAlternator 3 phase voltage unbalance shut downAlternator low and high frequency warning, shut downGenset over load shutdownAlternator 3 phase current unbalance shutdown
Battery chargering failure•Genset low and high voltage warning, shut down•Alternator 3 phase voltage unbalance shut down•Alternator low and high frequency warning, shut down•Genset over load shutdown•Alternator 3 phase current unbalance shutdown•
Battery chargering failure•Genset low and high voltage warning, shut down•Alternator 3 phase voltage unbalance shut down•Alternator low and high frequency warning, shut down•Genset over load shutdown•Alternator 3 phase current unbalance shutdown•
Alternator 3 phase voltage unbalance shut down • Alternator 1 ow and high frequency warning, shut down • Genset over load shutdown • Alternator 3 phase current unbalance shutdown •
Alternator 3 phase voltage unbalance shut down • Alternator 1 ow and high frequency warning, shut down • Genset over load shutdown • Alternator 3 phase current unbalance shutdown •
Alternator low and high frequency warning, shut down•Genset over load shutdown•Alternator 3 phase current unbalance shutdown•
Genset over load shutdown • Alternator 3 phase current unbalance shutdown •
Alternator 3 phase current unbalance shutdown
•
Mains low and high voltage warning
Mains low and high frequency warning
Optional
Remote start and stop
RS232 card x
USB card
RS485 card O
Multi language display O
GPRS communication



□Auto filling fuel pump □Manual filling fuel p

nk □1000L base frame fuel ta

□500LExternal fuel tank 🛛 🗌

□1000LExternal fuel tank

Electrical system

IC-NT Synchronizing controller

Maintenance spare parts



□500 hours genset spare parts

1000 hours genset spare parts